

BIOSECURITY MEASURES IN BEEKEEPING | VARROOSIS

Using Low-Impact Compounds Properly

Use of oxalic acid | Sublimation

To reduce the varroa mite level in the bee colony, when the colony is broodless, one option is sublimation of oxalic acid.

The following practice describes the use of a professional oxalic acid vaporizer. Available tools can be used with a standard 230V power supply or a 12V power supply (for example, a car battery) with an inverter.

The equipment used for the treatment.



step 1

Seal the mesh bottom and hive entrance. The method of sealing needs to be adapted to the construction of the hive.



step 2

Replace the cover with a special lid that fits with the device.



step 3

Fill oxalic acid crystals into the measure spoon that comes with the device.



step 4

Fill the ceramic container of the device with oxalic acid.



step 5

Hold the vaporizer upside down and insert the ceramic container.



step 6

Insert the nozzle of the device into the hole of the temporary lid. Then, turn the vaporiser 180 degrees so that the oxalic acid falls onto a hot element and vaporises. Wait until everything has vaporised.



step 7

Leave the lid and the seal in place for a few minutes before removing them and put the hive back to its original setting.



Copyright © Use of oxalic acid | Sublimation
All images © Karina Tomlund



Visit us
www.bthenet.eu

Contact us
info@bthenet.eu

Follow us
f @BTHENETProject

Our Consortium



Funded by the European Union

Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union. Neither the European Union nor the granting authority can be held responsible for them.